

ENTRÉ

HOW-TO GUIDE: APACHE TOMCAT CONFIGURATION



LT-1641 19171

INSTALL ENTRÉ ON THE APACHE TOMCAT SERVER

You must have Apache Tomcat software installed prior to deploying this file.

- 1 Stop the Apache Tomcat Service on the host machine.
- 2 Paste the **dmp.war** file into the **C:\Program Files\Apache Software Foundation\TomcatX.X\webapps** folder (where “X.X” represents the version number).
- 3 Start the Apache Tomcat Service on the host machine.
- 4 Open your web browser and use the following URL to access your client:
http://ipaddress:port/dmp/entre/start

CONFIGURE THE APACHE TOMCAT SERVER FOR ENTRÉ

- 1 Run **Tomcatw.exe** to configure the Apache Tomcat Server. The Dvx hostname should be the address of the App Server. See Figure 1.
- 2 Add the two settings below as new lines in the **Java Options** section.
 - **-XX:MaxPermSize=256M**
 - **-XX:+UseG1GC**
 - **-Xms256M**
 - **-Xmn64M**
 - **-Xmx384M**




Figure 1: Apache Tomcat Properties

3 If the Apache Server is running on a separate machine from the Entré Application server, add the following setting. This allows the machines to communicate with one another. See Figure 2.

- **-Dvx.hostname=<your hostname or IP Address>**




Figure 2: Hostname

CONFIGURE THE MEMORY POOLS

- 1 Set the **Initial memory pool** to at least 25% of machine memory.
- 2 Set the **Maximum memory pool** to around 50% of machine memory.



*Designed, engineered,
and manufactured in
Springfield, Missouri*

INTRUSION • FIRE • ACCESS • NETWORKS

2500 North Partnership Boulevard
Springfield, Missouri 65803-8877

800.641.4282 | dmp.com