

388 Printer Cable

Set the SG-DPU-414 Printer Software Dip Switches as listed in the table. Refer to the Operation Manual included with the printer as needed. Use the 388 Printer Cable to connect the SG-DPU-414 Printer to the SCS-1R Receiver.

Software DIP Switch 1		Software DIP Switch 2		Software DIP Switch 3	
1 (OFF)	Input = Serial	1 (OFF)	Printing Columns = 80	1 (ON)	Data Length = 8 bits
2 (ON)	Printing Speed = High	2 (ON)	User Font Back-up = ON	2 (ON)	Parity Setting = No
3 (ON)	Auto Loading = ON	3 (ON)	Character Select = Normal	3 (ON)	Parity Condition = Odd
4 (ON)	Auto LF = ON	4 (ON)	Zero = Normal	4 (ON)	Busy Control = H/W Busy
5 (ON)	Setting Command = Enable	5 (ON)	International	5 (ON)	Baud
6 (OFF)	Printing	6 (ON)	Character	6 (OFF)	Rate
7 (ON)	Density	7 (ON)	Set	7 (ON)	Select
8 (ON)	= 100%	8 (OFF)	= U.S.A.	8 (OFF)	= 1200 bps

