LX-Bus Zone Information

Assign Disarm condition for NT, DY, EX, A1, and A2 only.

Assign Prewarn and Entry Delay for EX only.

Assign Retard and Presignal for FI, SV, A1, A2, and PN only.

Zones_____ to _____

Zone Type Defaults

	Type	Area	Fire Bell	Wireless	DMP Wireless								FA Series Wireless				Disarmed Open			Disarmed Short			Armed Open			Armed Short									
	-- NT DY EX FI PN EM SV A1 A2 FV AR	INT PERIM BDRM or 1 to 32	Output *	N or Y	1101 Contact	1101 EXT Contact N/O?	1114 Contact	Supervision Time	1142 LED Operation	1126 Disarm Disable	1126 Pulse Count	1126 Sensitivity	Check-in Time	INT Contact	End-of-Line	Normally Open	Message	Output *	Action	Message	Output *	Action	Message	Output *	Action	Message	Output *	Action	Swinger	Prewarn	Entry Delay	Retard Delay	Presignal	Fast Response	Cross Zone	Priority	Style
					INT or EXT	N or Y	1 2 3 4	0 3 60 240	N or Y	N or Y	2 or 4	Low or High	None 10 30 60	N or Y	N or Y	N or Y	ATL–DSC		SPMF	ATL–DSC		SPMF	ATL–DSC		SPMF	ATL–DSC		SPMF	N or Y	1 to 16	1 2 3 or 4	N or Y	1 to 16	N or Y	N or Y	N or Y	TGL ARM DIS STEP MNT
NIGHT	NT			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N	–	0	S	–	0	S	A	0	S	A	0	S	Y					N	N	N	
DAY	DY			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N	T	0	S	T	0	S	A	0	S	A	0	S	Y					N	N	N	
EXIT	EX			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N	–	0	S	–	0	S	A	0	S	A	0	S	Y	1-16	1			N	N	N	
FIRE	FI		0	N	INT	N	1	240	Y	Y	4	Low	60	N	N	N							A	0	S	A	0	S	N			N	+	N	N	N	
PANIC	PN			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N							A	0	S	A	0	S	N			N	+	N	N	N	
EMERGENCY	EM			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N							A	0	S	A	0	S	N					N	N	N	
SUPERVISORY	SV		0	N	INT	N	1	240	Y	Y	4	Low	60	N	N	N							A	0	S	A	0	S	N			N	+	N	N	N	
AUXILIARY 1	A1			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N	T	0	S	A	0	S	A	0	S	A	0	S	N			N	+	N	N	N	
AUXILIARY 2	A2			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N	T	0	S	A	0	S	A	0	S	A	0	S	N			N	+	N	N	N	
FIRE VERIFY	FV		0	N	INT	N	1	240	Y	Y	4	Low	60	N	N	N				A	0		A	0	S	A	0	S	N					N		N	
ARMING	AR			N	INT	N	1	240	Y	Y	4	Low	60	N	N	N				A	0															TGL

#	Zone Name	Serial Number	*Output Options: 1 to 6, 450 to 474, 480 to 499, 500 to 999, D1 to D16, G1 to G20. +=Set retard to YES before selecting presignal. ■=Zone functions not available.

LX-Bus Zone Information

Assign Disarm condition for NT, DY, EX, A1, and A2 only.

Assign Prewarn and Entry Delay for EX only.

Assign Retard and Presignal for FI, SV, A1, A2, and PN only.

					Fire Bell		DMP Wireless								FA Series Wireless				Disarmed Open			Disarmed Short			Armed Open			Armed Short											
			Type	Area	Output*	Wireless	1101 Contact	1101 EXT Contact N/O?	1114 Contact	Supervision Time	1142 LED Operation	1126 Disarm Disable	1126 Pulse Count	1126 Sensitivity	Check-in Time	INT Contact	End-of-Line	Normally Open	Message	Output *	Action	Message	Output *	Action	Message	Output *	Action	Message	Output *	Action	Swinger	Prewarn	Entry Delay	Retard Delay	Presignal	Fast Response	Cross Zone	Priority	Style
#	**Zone Name**	**Serial Number**	*Output Options: 1 to 6, 450 to 474, 480 to 499, 500 to 999, D1 to D16, G1 to G20.																																				

800-641-4282
www.dmp.com
Designed, Engineered and Assembled in U.S.A.
INTRUSION • FIRE • ACCESS • NETWORKS
2500 North Partnership Boulevard
Springfield, Missouri 65803-8877

LT-0286 © 2013 Digital Monitoring Products, Inc.

8324