





## MESSAGING SETUP

Enable Messaging **NO** YES  
 System Name \_\_\_\_\_  
 Destination 1 \_\_\_\_\_  
 Destination 1 User Number - - - - -  
 Destination 2 \_\_\_\_\_  
 Destination 2 User Number - - - - -  
 Destination 3 \_\_\_\_\_  
 Destination 3 User Number - - - - -  
 Email Comm Type **NET** CELL  
 O/C Email **NO** YES  
 O/C SMS **NO** YES  
 Monthly Limit - - - - (0-999, Default = 0)  
 SMTP Server \_\_\_\_\_  
 SMTP Port - - - - -  
 SMTP Username \_\_\_\_\_  
 SMTP Password \_\_\_\_\_  
 From Email \_\_\_\_\_

## REMOTE OPTIONS

Remote Key - - - - -  
 Remote Disarm **NO** YES  
 Armed Answer Rings - - (0 to 15, default = 8)  
 Disarmed Answer Rings - - (0 to 15, default = 8)  
 PC Modem **NO** YES  
 Alarm Receiver Auth **NO** YES  
 Service Receiver Auth NO **YES**  
 Manufacturer Auth **NO** YES  
 Allow Network Remote NO **YES**  
 Network Programming Port - - - - (Default = 2001)  
 Encrypt Network Remote **NO** YES  
 Allow Cellular Remote NO **YES**  
 First GPRS APN - - - - -  
 (Default = SECURECOM400)  
 Second GPRS APN - - - - -  
 (Default = SECURECOM400)  
 Encrypt Cellular Remote **NO** YES  
 Entre Connection **NONE** NET  
 Entre Incoming TCP Port - - - - (Default = 2011)  
 Entre IP Address - - - - -  
 Entre Outbound TCP Port - - - - (Default = 2001)  
 Entre Backup IP Address - - - - -  
 Entre Backup TCP Port - - - - (Default = 2001)  
 Entre Checkin Minutes - - - (0, 3-240 minutes, default = 0)  
 Entre Passphrase - - - - -  
 Send Local Changes **NO** NET DD  
 Remote Change IP - - - - -  
 Remote Change Port - - - - (Default = 2002)  
 Remote Phone No - - - - -

## SYSTEM REPORTS

Abort Reports **NO** YES  
 Restoral Reports NO **YES** DISARM  
 Bypass Reports NO **YES**  
 Schedule Change Rpts NO **YES**  
 Code Change Reports NO **YES**  
 Access Keypads **1 2 3 4 5 6 7 8**  
 Ambush **NO** YES

## SYSTEM OPTIONS

System **AREA** A/P H/A GST  
 Instant Arming **NO** YES  
 Closing Wait **NO** YES  
 Entry Delay 1 - - - - (30 to 250 sec, default = 30)  
 Entry Delay 2 - - - - (30 to 250 sec, default = 60)  
 Entry Delay 3 - - - - (30 to 250 sec, default = 90)  
 Entry Delay 4 - - - - (30 to 250 sec, default = 120)  
 Cross Zone Time - - - - (4 to 250 sec, default = 4)  
 Zone Retard Delay - - - - (0 to 250 sec, default = 10)  
 Power Fail Delay Hrs - - - (0 to 15 hours, default = 1)  
 Swinger Bypass Trips - - - (0 to 6, default = 2)  
 Reset Swngr Bypass **NO** YES  
 Time Change NO **YES**  
 Hours from GMT - - - (0 to 23, default = 6)  
 Latch Supervisory NO **YES**  
 Programming Language  
 Primary Language **ENGLISH** SPANISH FRENCH  
 Secondary Language **NONE** ENG SPN FRN  
 User Language  
 Primary Language **ENGLISH** SPANISH FRENCH  
 Secondary Language **NONE** ENG SPN FRN  
 Bypass Limit - - - (0 to 8, default = 0)  
 Wireless House Code - - - (0, 1 to 50, 99, default = 0)  
 Detect Wireless Jamming **NO** YES  
 Wireless Audibles ANY **DAY** MIN  
 Enable Keypad Panic Keys NO **YES**  
 Occupied Premise NO **YES**  
 Enhanced Zone Test **NO** YES  
 Send 16 Character Names NO **YES**  
 Keypad Armed LED **ALL** ANY  
 Use False Alarm Question **NO** YES

## BELL OPTIONS

Bell Cutoff Time - - - (0 to 99 minutes, default = 15)  
 Automatic Bell Test **NO** YES  
 Bell Output - - - -  
**Bell Action . . .**  
 Fire Zones Steady **Pulse** Temporal None  
 Burglary Zones **Steady** Pulse Temporal None  
 Supervisory Zones Steady Pulse Temporal **None**  
 Panic Zones Steady Pulse Temporal **None**  
 Emergency Zones Steady Pulse Temporal **None**  
 Auxiliary 1 Zones Steady Pulse Temporal **None**  
 Auxiliary 2 Zones Steady Pulse Temporal **None**

## OUTPUT OPTIONS

Cutoff Output 1 2 3 4 5 6  
 Cutoff Time - - - - (0 to 99 minutes, default = 0)  
 Comm Fail Output - - - -  
 Fire Alarm Output - - - - Phone Trouble Output - - - -  
 Fire Trouble Output - - - - Late to Close Output - - - -  
 Panic Alarm Output - - - - Device Fail Output - - - -  
 Ambush Output - - - - Sensor Reset Output - - - -  
 Entry Output - - - - Closing Wait Output - - - -  
 Exit Output - - - - Arm-Alarm Output - - - -  
 Ready Output - - - - Supv Alarm Output - - - -







**Contents**

<b>NETWORK OPTIONS (XR500N/XR500E only)</b>	<b>2</b>	
<b>MESSAGING SETUP</b>	<b>2</b>	
<b>MESSAGING SETUP (Continued)</b>	<b>2</b>	
<b>DEVICE SETUP (continued)</b>	<b>2</b>	
<b>DEVICE SETUP</b>	<b>2</b>	
<b>REMOTE OPTIONS</b>	<b>3</b>	
<b>SYSTEM REPORTS</b>	<b>3</b>	
<b>SYSTEM OPTIONS</b>	<b>3</b>	
<b>BELL OPTIONS</b>	<b>3</b>	
<b>OUTPUT OPTIONS</b>		<b>3</b>
<b>OUTPUT INFORMATION</b>	<b>3</b>	
<b>MENU DISPLAY</b>	<b>4</b>	
<b>STATUS LIST</b>	<b>4</b>	
<b>PRINTER REPORTS</b>	<b>4</b>	
<b>PC LOG REPORTS</b>	<b>4</b>	
<b>AREA INFORMATION</b>	<b>4</b>	
<b>AREA INFORMATION</b>	<b>5</b>	
<b>KEYPAD/LX-BUS ZONE INFORMATION</b>		<b>6</b>