

XR6/XR10 PROGRAMMING SHEET

Name _____ Account Number _____ Date _____
 Address _____ City _____ State _____ Zip _____

COMMUNICATION

Communication Type **NONE** DD 4 - 2 CID
 Account Number _ _ _ _ _ (1 to 65,535)
 Transmission Delay _ _ (0 to 60 sec)
 DTMF **NO** **YES**
 Defer Recall Test **NO** YES
 Test Frequency _ _ (1 to 60 days)

Receiver 1

Alarm **NO** **YES**
 Supv/Trouble **NO** **YES**
 O/C & User **NO** **YES**
 Test Report **NO** **YES**
 Backup **NO** YES

First Phone #: _____
 Second Phone #: _____

Receiver 2

Pager **NO** YES
 Alarm **NO** YES
 Supv/Trouble **NO** YES
 O/C & User **NO** YES
 Test Report **NO** YES
 Backup **NO** YES

First Phone #: _____
 Second Phone #: _____
 Pager ID #: _____

REMOTE OPTIONS

Remote Key _____
 Manufact. Auth. **NO** YES
 Armed Rings _ _ (0 to 15)
 Disarmed Rings _ _ (0 to 15)
 Alarm Receiver **NO** YES
 Service Receiver **NO** **YES**
 Disarm **NO** YES

SYSTEM REPORTS

Open / Close Reports **NO** YES
 Abort Reports **NO** **YES**
 Zone Restoral Reports **NO** **YES** DISARM
 Bypass Reports **NO** **YES**
 Code Change Reports **NO** YES
 Ambush **NO** YES

SYSTEM OPTIONS

All / Perimeter **NO** YES
 Closing Code **NO** YES
 Entry Delay 1 _ _ _ (0 to 250 secs)
 Entry Delay 2 _ _ _ (0 to 250 secs)
 Exit Delay _ _ _ (0 to 250 secs)
 Cross Zone Time _ _ _ (0 to 250 secs)
 Power Fail Delay _ (0 to 9 hrs)
 Reset Swinger Bypass **NO** **YES**

OUTPUT OPTIONS

Bell Cutoff Time _ _ (0 to 15 mins.)
Bell Action . . .
 Fire Zones Steady **Pulse** Temporal None
 Supervisory Zones Steady Pulse Temporal **None**
 Panic Zones Steady Pulse Temporal **None**
 Emergency Zones Steady Pulse Temporal **None**
 Auxiliary 1 Zones Steady Pulse Temporal **None**
 Auxiliary 2 Zones Steady Pulse Temporal **None**
Output Action . . .
 Cutoff Outputs 1 2 3 4
 Cutoff Time _ _ (0 to 15 mins)
 Comm Fail Output _ (0 to 4)
 Fire Alarm Output _ (0 to 4)
 Fire Trouble Output _ (0 to 4)
 Ambush Output _ (0 to 4)
 Entry Output _ (0 to 4)
 Exit Output _ (0 to 4)
 Ready Output _ (0 to 4)
 Armed Output _ (0 to 4)
 Burglary Output _ (0 to 4)
 Ground Start Output _ (0 to 4)

Note: Factory defaults are shown in **bold** type.

XR6/XR10 Zone Information

XR6/XR10 ZONE INFORMATION	Type	Area	Disarmed Open			Disarmed Short			Armed Open			Armed Short			Swinger	Entry Delay	Cross Zone	Priority
			Message	Output	Action	Message	Output	Action	Message	Output	Action	Message	Output	Action				
Assign Area & Disarmed condition for NT, DY, EX, A1, A2, AR only	-- NT DY EX FI PN EM SV A1 A2 FV AR	INT BDRM PERIM	A	1	S	A	1	S	A	1	S	A	1	S	N	1	N	N
Assign Entry Delay for EX only			L	to	P	L	to	P	L	to	P	L	to	P	or	or	or	or
Zone Type Defaults	Abbr.		-	4	M	-	4	M	-	4	M	-	4	M	Y	2	Y	Y
NIGHT	NT	PERIM	-	O	-	-	O	-	A	O	-	A	O	-	Y		N	N
DAY	DY	PERIM	T	O	-	T	O	-	A	O	-	A	O	-	Y		N	N
EXIT	EX	PERIM	-	O	-	-	O	-	A	O	-	A	O	-	Y	1	N	N
FIRE	FI								T	O	-	A	O	-	N		N	N
PANIC	PN								T	O	-	A	O	-	N		N	N
EMERGENCY	EM								T	O	-	A	O	-	N		N	N
SUPERVISORY	SV								T	O	-	A	O	-	N		N	N
AUXILIARY 1	A1	PERIM	T	O	-	A	O	-	T	O	-	A	O	-	N		N	N
AUXILIARY 2	A2	PERIM	T	O	-	A	O	-	T	O	-	A	O	-	N		N	N
FIRE VERIFY	FV								T	O	-	A	O	-	N			N
ARMING	AR	ALL																
No.	Name																	
1	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
2	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
3	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
4	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
5	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
6	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
7	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
8	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
9	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___
10	_____	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___	___

■ = These zone functions are not available for this zone type.

- = Default Message or Output Action not defined.

Note: When using the XR6 panel, zones 7-10 appear on keypad address number one.

	800-641-4282	INTRUSION • FIRE • ACCESS • NETWORKS
	www.dmp.com	2500 North Partnership Boulevard
	Made in the USA	Springfield, Missouri 65803-8877