

MESSAGING SETUP

Enable Messaging **NO** YES
 System Name _____
 Destination 1 _____
 Destination 1 User Number - - - - -
 Destination 2 _____
 Destination 2 User Number - - - - -
 Destination 3 _____
 Destination 3 User Number - - - - -
 Email Comm Type **NET** CELL
 O/C Email **NO** YES
 O/C SMS **NO** YES
 Monthly Limit - - - - (0-999, Default = 0)
 SMTP Server _____
 SMTP Port - - - - -
 SMTP Username _____
 SMTP Password _____
 From Email _____

REMOTE OPTIONS

Remote Key - - - - -
 Remote Disarm **NO** YES
 Armed Answer Rings - - (0 to 15, default = 8)
 Disarmed Answer Rings - - (0 to 15, default = 8)
 PC Modem **NO** YES
 Alarm Receiver Auth **NO** YES
 Service Receiver Auth NO **YES**
 Manufacturer Auth **NO** YES
 Allow Network Remote NO **YES**
 Network Programming Port - - - - (Default = 2001)
 Encrypt Network Remote **NO** YES
 Allow Cellular Remote NO **YES**
 First GPRS APN - - - - -
 (Default = SECURECOM400)
 Second GPRS APN - - - - -
 (Default = SECURECOM400)
 Encrypt Cellular Remote **NO** YES
 Allow RS-232 Remote NO **YES**
 Entre Connection **NONE** NET
 Entre Incoming TCP Port - - - - (Default = 2011)
 Entre IP Address - - - - . - - - . - - - . - - -
 Entre Outbound TCP Port - - - - (Default = 2001)
 Entre Backup IP Address - - - - . - - - . - - - . - - -
 Entre Backup TCP Port - - - - (Default = 2001)
 Entre Checkin Minutes - - - (0, 3-240 minutes, default = 0)
 Entre Passphrase - - - - -
 Send Local Changes **NO** NET DD
 Remote Change IP - - - - . - - - . - - - . - - -
 Remote Change Port - - - - (Default = 2002)
 Remote Phone No - - - - -

SYSTEM REPORTS

Abort Reports **NO** YES
 Restoral Reports NO **YES** DISARM
 Bypass Reports NO **YES**
 Schedule Change Rpts NO **YES**
 Code Change Reports NO **YES**
 Access Keypads **1 2 3 4 5 6 7 8**
9 10 11 12 13 14 15 16
 Ambush **NO** YES

SYSTEM OPTIONS

System **AREA** A/P H/A GST
 Instant Arming **NO** YES
 Closing Wait **NO** YES
 Entry Delay 1 - - - - (30 to 250 sec, default = 30)
 Entry Delay 2 - - - - (30 to 250 sec, default = 60)
 Entry Delay 3 - - - - (30 to 250 sec, default = 90)
 Entry Delay 4 - - - - (30 to 250 sec, default = 120)
 Cross Zone Time - - - - (4 to 250 sec, default = 4)
 Zone Retard Delay - - - - (0 to 250 sec, default = 10)
 Power Fail Delay Hrs - - - (0 to 15 hours, default = 1)
 Swinger Bypass Trips - - - (0 to 6, default = 2)
 Reset Swngnr Bypass **NO** YES
 Time Change NO **YES**
 Hours from GMT - - - (0 to 23, default = 6)
 Latch Supervisory NO **YES**
 Programming Language
 Primary Language **ENGLISH** SPANISH FRENCH
 Secondary Language **NONE** ENG SPN FRN
 User Language
 Primary Language **ENGLISH** SPANISH FRENCH
 Secondary Language **NONE** ENG SPN FRN
 Bypass Limit - - - (0 to 8, default = 0)
 Card Plus PIN (XR500E) **NO** YES
 Wireless House Code - - - (0, 1 to 50, 99, default = 0)
 Detect Wireless Jamming **NO** YES
 Wireless Audibles ANY **DAY** MIN
 Enable Keypad Panic Keys NO **YES**
 Occupied Premise NO **YES**
 Enhanced Zone Test **NO** YES
 Send 16 Character Names NO **YES**
 Keypad Armed LED **ALL** ANY
 Use False Alarm Question **NO** YES
 Change Own User Code **NO** YES
 Panic Supervision **NO** YES
 Weather Zip Code - - - - - Default = 0

BELL OPTIONS

Bell Cutoff Time - - - (0 to 99 minutes, default = 15)
 Automatic Bell Test **NO** YES
 Bell Output - - - -
Bell Action . . .
 Fire Zones Steady **Pulse** Temporal None
 Burglary Zones **Steady** Pulse Temporal None
 Supervisory Zones Steady Pulse Temporal **None**
 Panic Zones Steady Pulse Temporal **None**
 Emergency Zones Steady Pulse Temporal **None**
 Auxiliary 1 Zones Steady Pulse Temporal **None**
 Auxiliary 2 Zones Steady Pulse Temporal **None**

OUTPUT OPTIONS

Cutoff Output 1 2 3 4 5 6
 Cutoff Time - - - - (0 to 99 minutes, default = 0)
 Comm Fail Output - - - -
 Fire Alarm Output - - - - Phone Trouble Output - - - -
 Fire Trouble Output - - - - Late to Close Output - - - -
 Panic Alarm Output - - - - Device Fail Output - - - -
 Ambush Output - - - - Sensor Reset Output - - - -
 Entry Output - - - - Closing Wait Output - - - -
 Exit Output - - - - Arm-Alarm Output - - - -
 Ready Output - - - - Supv Alarm Output - - - -

