


XTLplus-GW Programming Sheet

NAME _____ ACCOUNT NUMBER _____ DATE _____
 ADDRESS _____ CITY _____ STATE _____ ZIP _____

 While filling out this programming sheet, keep in mind that factory default values are shown in **bold**.

COMMUNICATION

Account Number _____ (1 to 65,535 default = **12345**)
 Transmission Delay ____ (0, 15 to 45 sec., default = **30**)
 Communication Type **WIFI** CELL NONE
 Backup Cell **NO** YES
 Test Time ____ : ____ **AM** PM
 Wi-Fi Test Days ____ (0 to 60 days, default = **1**)
 Cell Test Days ____ (0 to 60 days, default = **1**)
 Check-In Minutes ____ (0, or 3 to 240 min., default = **200**)
 Fail Time ____ (0, or 3 to **240** min.)
 Send Comm Trouble **NO** YES
 First Cell APN **SECURECOM400**

 Second Cell APN _____

Receiver 1 Programming:

Alarm Reports NO **YES**
 Supv/Trouble NO **YES**
 O/C & User **NO** YES
 Test Report NO **YES**
 First IP Address _____
 First IP Port _____ (default = **2001**)
 Second IP Address _____
 Second IP Port _____ (default = **2001**)

Receiver 2 Programming:

Alarm Reports **NO** YES
 Supv/Trouble **NO** YES
 O/C & User **NO** YES
 Test Report **NO** YES
 First IP Address _____
 First IP Port _____ (default = **2001**)
 Second IP Address _____
 Second IP Port _____ (default = **2001**)

NETWORK OPTIONS

WPS **NO** YES
 SSID _____

 Wireless Security W64 W128 WPA **WPA2**
 NONE
 Wireless Key _____

 DHCP **NO** **YES**
 Local IP Address _____
 Gateway Address _____
 Subnet Mask _____
 DNS Server _____
 Programming Port _____ (default = **2001**)

MESSAGING SETUP

Enable Messaging **NO** YES
 System Name _____

 Destination 1 _____

 Destination 1 User Number ____

MESSAGING SETUP (CONTINUED)

Destination 2 _____

 Destination 2 User Number ____
 Destination 3 _____

 Destination 3 User Number ____
 O/C SMS **NO** YES
 Monthly Limit _____ (0-999, default = **0**)

DEVICE SETUP

Device 1
 Device Name _____
Device 2
 Device Name _____
 Wireless NO **YES** Serial # _____
 Supervision Time 0 60 **240**
Device 3
 Device Name _____
 Wireless NO **YES** Serial # _____
 Supervision Time 0 60 **240**
Device 4
 Device Name _____
 Wireless NO **YES** Serial # _____
 Supervision Time 0 60 **240**
Device 5
 Device Name _____
 Wireless NO **YES** Serial # _____
 Supervision Time 0 60 **240**

REMOTE OPTIONS

Remote Key _____
 Manufacturer Authorization **NO** YES
 Alarm Receiver **NO** YES
 Service Receiver **NO** YES
 Disarm NO **YES**
 App Key _____

SYSTEM REPORTS

Opening/Closing Reports **NO** YES
 Abort Reports **NO** YES
 Zone Restoral Reports NO **YES** DISARM
 Bypass Reports NO **YES**
 Code Change Reports **NO** YES
 Send Stored Messages **NO** YES
 Ambush Reports **NO** YES
 Late To Open Minutes ____ (0 to 240 min.)
 Early To Close Minutes ____ (0 to 240 min.)

SYSTEM OPTIONS

System AREA A/P **H/A**
 Closing Code **NO** YES
 Closing Check **NO** YES
 Entry Delay 1 ____ (30 to 250 sec., default = **30**)
 Entry Delay 2 ____ (30 to 250 sec., default = **60**)
 Exit Delay ____ (45 to 250 sec., default = **60**)
 Cross Zone Time ____ (0, 4 to 250 sec.)

SYSTEM OPTIONS (CONTINUED)

Table with 3 columns: Option Name, Value, and Description. Options include Power Fail Delay, Swinger Bypass Trips, Reset Swinger Bypass, Zone Activity Hours, Arm Activity Days, Time Change, Hours from GMT, Time Display, House Code, Detect Wireless Jamming, Wireless Audibles, Enable Keypad Panic Keys, Occupied Premises, Use False Alarm Question, and Weather Zip Code.

BELL OPTIONS

Table with 3 columns: Option Name, Value, and Description. Options include Bell Cutoff Time, Automatic Bell Test, and Bell Output.

Bell Action . . .

Table with 5 columns: Zone Name, Steady, Pulse, Temporal, and None. Options include Fire Zones, Burglary Zones, Supervisory Zones, Panic Zones, Emergency Zones, Auxiliary 1 Zones, and Auxiliary 2 Zones.

OUTPUT OPTIONS

Table with 3 columns: Option Name, Value, and Description. Options include Comm Fail Output, Fire Alarm Output, Panic Alarm Output, Entry Output, Begin Exit Output, End Exit Output, Ready Output, Armed Home Output, Armed Sleep Output, Armed Away Output, Armed All Output, Armed Perim Output, Armed Output, Disarmed Output, Burglary Output, Arm-Alarm Output, Heat Saver Temperature, and Cool Saver Temperature.

OUTPUT SETUP (WIRELESS)

Output 51

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

Output 52

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

Output 53

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

OUTPUT SETUP (CONTINUED)

Output 54

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

Output 61

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

Output 62

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

Output 63

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

Output 64

Table with 3 columns: Option Name, Value, and Description. Options include Output Name, Serial #, Supervision Time, and Trip with Panel Bell.

Note: Assign Output Numbers 51 to 54 for slow response time wireless outputs (activates within 15 seconds) or 61 to 64 for fast response time wireless outputs (activates within 1 second). Assign an 1135 Wireless Siren to any output number and it operates with a fixed 3 second response.

AREA INFORMATION

Area 1

Table with 3 columns: Option Name, Value, and Description. Options include Area Name, Auto Arming, Bad Zones, and Auto Disarming.

Area 2

Table with 3 columns: Option Name, Value, and Description. Options include Area Name, Auto Arming, Bad Zones, and Auto Disarming.

Area 3

Table with 3 columns: Option Name, Value, and Description. Options include Area Name, Auto Arming, Bad Zones, and Auto Disarming.

Area 4

Table with 3 columns: Option Name, Value, and Description. Options include Area Name, Auto Arming, Bad Zones, and Auto Disarming.

Area 5

Table with 3 columns: Option Name, Value, and Description. Options include Area Name, Auto Arming, Bad Zones, and Auto Disarming.

Area 6

Table with 3 columns: Option Name, Value, and Description. Options include Area Name, Auto Arming, Bad Zones, and Auto Disarming.

